

Mini Erbium Doped Fiber Amplifier



DATASHEET

[Return to the Webpage](#)

Features

- Low Noise
- High Stability
- Miniature Size
- 2.5/10/100G Channel Amplification

Applications

- BOTDR
- OTDR
- LiDAR
- Fiber sensing



Legal notices: All product information is believed to be accurate and is subject to change without notice. Information contained herein shall legally bind Agiltron only if it is specifically incorporated into the terms and conditions of a sales agreement. Some specific combinations of options may not be available. The user assumes all risks and liability whatsoever in connection with the use of a product or its application.

Rev 06/10/26

The Mini Erbium-Doped Fiber Amplifier (MEDF) is a high-performance, compact optical solution designed for reliable signal amplification at data rates up to 100 Gbps. This unit integrates an uncooled pump laser to minimize power consumption and features dual operating modes — Automatic Current Control (ACC) and Automatic Power Control (APC) — allowing users to choose between a constant pump current or a stabilized output power via a user-friendly USB-connected GUI. Built with high-quality components and internal isolators to prevent back-reflection, the MEDF is engineered for a 10-year operational lifespan, supported by advanced thermal management and real-time monitoring features like Loss of Signal (LOS) alarms and pump protection.

Specifications

Parameter	Min	Typical	Max	Unit
Wavelength	1525	1550	1565	nm
Input Power	-15	-12	5	dBm
Output Power	6		18	dBm
Gain ^[1]		24		dB
Noise	1		5.5	dB
Gain Flatness		3		dB
Polarization Dependent Gain			0.3	dB
Return Loss	40			dB
Polarization Mode Dispersion			0.5	ps
Input/output Isolation	35			dB
Output Stability (8hrs)			± 0.1	dB
Adjustable Output Power Accuracy			± 0.5	dB
Over Temperature Alarm Setting	25		70	°C
Fiber Type	SMF-28, 9/125um NA = 0.13			
Working Temperature	-30		55	°C
Storage Temperature	-45		85	°C
Operation Humidity	5		85	%
Module Power Supply	3.15		3.46	V
Adapt PCB Power Supply	DC +5V / GND			
Power Consumption/Dissipation		0.8		W
Size		34x22x11		mm
PCB Adaptor Communication		USB		

Notes:

[1]. @Output power=5dBm. Define as amplification: Output power = Gain X Input power.

Note: The specifications provided are for general applications with a cost-effective approach. If you need to narrow or expand the tolerance, coverage, limit, or qualifications, please [click this link](#):

+1 781-935-1200

sales@agiltron.com


www.agiltron.com

Information contained herein is deemed to be reliable and accurate as of the issue date. We reserve the right to change the design or specifications at any time without notice. Agiltron is a registered trademark of Optowares Corporation in the U.S. and other countries.

Mini Erbium Doped Fiber Amplifier

DATASHEET

Function Diagram



Package Choices



Component



USB/GUI Adopting PCB mounted on top of the component for convenience

Mini Erbium Doped Fiber Amplifier



DATASHEET

GUI USB Interface

AGILTRON INC.

Choose Device Model

EDFA-H

Connect to Amplifier

--Select- Refresh Connect

Monitor Status

Set Amplifier Parameters

Check Settings Pump ON Pump OFF

Control Mode: Set Power(dBm) Set Current(mA)

Set Set Set

Clear Save Settings to Amplifier

Command Log

Operation Instruction

- Load the software, Unzip the folder and Click "setup" to Install the GUI
- Select an amplifier type that matches your PO
- Connect your PC to the Amplifier by first connecting a USB cable and then choosing the necessary port and clicking "Connect". To change the COM port click "Refresh", choose the necessary port, then click "Connect"
- Obtain the stored settings by clicking "Check Settings"
- To change the setting, first select the control mode
- To set up output power or current, input desired value and click "Set". There are limits for max output per the model type.
- To turn on the Amplify click "Pump ON"; the green color should appear. To stop click "Pump OFF"; the red color should appear
- To save the setting click "Save Settings to Amplifier". The Amplifier will store the setting for the next time you turn it on, even without the PC.
- The Amplifier only works if the input optical power level is within the spec.

+1 781-935-1200

sales@agiltron.com

www.agiltron.com

Information contained herein is deemed to be reliable and accurate as of the issue date. We reserve the right to change the design or specifications at any time without notice. Agiltron is a registered trademark of Optowares Corporation in the U.S. and other countries.

Mini Erbium Doped Fiber Amplifier



DATASHEET

Control GUI

EDFA GUI V3.0

AGILTRON INC

Choose Device Model
EDFA-L

Connect to Amplifier
COM7 Refresh Disconnect

Monitor Status

Opt.IN	-0.34 dBm
Opt.Out	15 dBm
BIAS-1	417 mA
CoolCurr-1	0 mA
LaserTemp-1	26.2 °C
Modul Temp	25.1 °C
PumpPower	21.67 dBm
Power Voltage	4.93 V
GAIN	15.31 dB
ALARM:	No Alarms
Model:	EDFA-20dBm
SN:	220728001

Set Amplifier Parameters

Check Settings Pump ON Pump OFF

Control Mode: Set Power(dBm) Set Current(mA)

Power control 15 Set 600 Set

Power control

Current control

Gain control 23 Set

Command Log

Port connected
Get Sn/Model Success
Power Control Mode: Success
Check Settings: Success

Threshold settings

Module Temp Threshold	-5	- 55	°C	Set	Input Power LOS Threshold	-33	dBm	Set
Pump Temp Threshold	0	- 40	°C	Set	Output Power LOS Threshold	-8	dBm	Set
Pump Current Threshold	1200		mA	Set	No Optical Power Threshold	-33	dBm	Set

+1 781-935-1200

sales@agiltron.com

www.agiltron.com




Information contained herein is deemed to be reliable and accurate as of the issue date. We reserve the right to change the design or specifications at any time without notice.
Agiltron is a registered trademark of Optowares Corporation in the U.S. and other countries.

Mini Erbium Doped Fiber Amplifier




DATASHEET

Output Power Stability (33dBm Benchtop)



Mechanical Dimensions (mm)



*Product dimensions may change without notice. This is sometimes required for non-standard specifications.

P +1 781-935-1200

E sales@agiltron.com

W www.agiltron.com

Information contained herein is deemed to be reliable and accurate as of the issue date. We reserve the right to change the design or specifications at any time without notice. Agiltron is a registered trademark of Optowares Corporation in the U.S. and other countries.

Mini Erbium Doped Fiber Amplifier



DATASHEET

Electrical Parameters

Power Supply

Parameter	Min	Typical	Max	Unit	Note
Voltage	3.15	3.3	3.45	V	
Current	-	-	1.0	A	
Power Consumption	-	-	3.45	W	

Wiring

Wire Color	Function	Description
Red	Power +	3.3 DCV
Black	Power -	GND
White	En (enable)	TTL low: enable pump
Yellow	LVTTL-Tx	Transmit
Blue	LVTTL-Rx	Receive



Ports of EDFA

Note: Heatsink must be attached to the EDFA for good performance and to avoid damage to EDFA.

+1 781-935-1200

sales@agiltron.com

www.agiltron.com

Information contained herein is deemed to be reliable and accurate as of the issue date. We reserve the right to change the design or specifications at any time without notice. Agiltron is a registered trademark of Optowares Corporation in the U.S. and other countries.

Mini Erbium Doped Fiber Amplifier



DATASHEET

Ordering Information (Part Number)

	1	☐	☐	1	☐	☐	☐	☐	☐
Prefix	Type	Wavelength	Power ^[1]	Polarization	Package	Cable Type	Fiber Length ^[2]	Connector ^[3]	Filter
MEDF-		C Band = C Special = 0	10dBm = 2 18dBm = 3	Random = 1	Component = M PCB Mount = P Special = 0	0.9mm tube = 3 Special = 0	0.5m = 2 1.0m = 3 Special = 0	None = 1 FC/PC = 2 FC/APC = 3 SC/PC = 4 SC/APC = 5 LC/PC = 7 LC/APC = A LC/UPC = U Special = 0	None = 1 Gain flat = 2 Special = 0

[1]. For Booster, Power means maximum output power. For Preamp, Power means maximum amplification gain.

[2]. For >1W modules, the fiber cables extrude out of the front.

[3]. The default connector configuration uses fiber with 0.9 mm buffer protection. The connector cannot be installed directly onto bare fiber because the bare fiber is prone to damage during shipping. However, the connector can be assembled on bare fiber if a 3 cm protective loose tube is added for reinforcement. The customer may remove this protective tube after testing. The optical power handling of a standard connector is less than 0.5 W for SMF-28 fiber and decreases further for smaller-core fibers.

Application Notes

Fiber Core Alignment

Note that the minimum attenuation for these devices depends on excellent core-to-core alignment when the connectors are mated. This is crucial for shorter wavelengths with smaller fiber core diameters that can increase the loss of many decibels above the specification if they are not perfectly aligned. Different vendors' connectors may not mate well with each other, especially for angled APC.

Fiber Cleanliness

Fibers with smaller core diameters (<5 μm) must be kept extremely clean, contamination at fiber-fiber interfaces, combined with the high optical power density, can lead to significant optical damage. This type of damage usually requires re-polishing or replacement of the connector.

Maximum Optical Input Power

Due to their small fiber core diameters for short wavelength and high photon energies, the damage thresholds for device is substantially reduced than the common 1550nm fiber. To avoid damage to the exposed fiber end faces and internal components, the optical input power should never exceed 20 mW for wavelengths shorter 650nm. We produce a special version to increase the how handling by expanding the core side at the fiber ends.

+1 781-935-1200

sales@agiltron.com

www.agiltron.com

Information contained herein is deemed to be reliable and accurate as of the issue date. We reserve the right to change the design or specifications at any time without notice.
Agiltron is a registered trademark of Optowares Corporation in the U.S. and other countries.

Mini Erbium Doped Fiber Amplifier



DATASHEET

Q&A About Fiber Optical Amplifier

Q: What is the polarization state of the output?

A: The erbium-doped fiber core is effectively isotropic, so any input polarization becomes scrambled through propagation and gain interactions. The output's degree of polarization is typically low because the EDFA generates significant ASE, which further washes out any residual polarization.

Q: Why EDFA is limited to amplification above 1530nm?

A: The EDFA gain spectrum is set by the Er^{3+} energy levels in silica glass, and the emission cross-section falls off rapidly as you move toward shorter wavelengths.

Q: Can this amplifier pulsed signals?

A: It has been tested to amplify up to 100GHz digital data. But high power pulse will induce non-linear effects that broaden it.

Q: Can this amplifier WDM signals?

A: It has been tested to amplify signals with DWDM wavelength spacing.

Q: Can this amplifier has a flat wavelength response?

A: Yes, by put flattering gain filters, that is an extra cost.

Q: If one puts a small signal into it, can it be amplified to the maximum output power indicated on the spec?

A: The amplifier is set as an analog mode whose output signal strength is approximately proportional to the input strength. It has a certain gain of about 40dB. There are two types: one is a preamplifier and a booster. One can use a preamplifier before the booster for weak signals, as done in electronic amplifiers.

Q: We have an existing amplifier. Can you duplicate it?

A: Yes, we can produce it with a seamless software interface.

Q: The control mode is selectable in the GUI, does this mean it can be operated in either APC, ACC, or CC mode? (i.e. can you support all 3 control modes in a single system)

A: MSA EDFA: APC, ACC & CC (AGC).
EYDFA (MSA & standard) : APC & ACC

Q: Do the MSA packages work with the Agiltron GUI?

A: Yes

Q: Do you have preamplifier with -35 and -40dBm input power?

A: Yes, available in different package.

Q: Does the Preamplifier come with APC or ACC control mode and which control mode achieves better receive sensitivity?

A: Under ACC mode, EDFA will amplify any input if you choose the always-on pump option.

Q: If we want to control the EDFA without the GUI, do you have a list of the RS232 commands?

A: It comes with each EDFAs.

Mini Erbium Doped Fiber Amplifier



DATASHEET

Laser Safety

This product meets the appropriate standard in Title 21 of the Code of Federal Regulations (CFR). FDA/CDRH Class 1M laser product. This device has been classified with the FDA/CDRH under accession number 0220191. All versions of this laser are Class 1M laser products, tested according to IEC 60825-1:2007 / EN 60825-1:2007. An additional warning for Class 1M laser products. For diverging beams, this warning shall state that viewing the laser output with certain optical instruments (for example eye loupes, magnifiers, and microscopes) within a distance of 100 mm may pose an eye hazard. For collimated beams, this warning shall state that viewing the laser output with certain instruments designed for use at a distance (for example telescopes and binoculars) may pose an eye hazard.

Wavelength = 1.3/1.5 μm .

Maximum power = 30 mW.



*Caution - Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.

*IEC is a registered trademark of the International Electrotechnical Commission.

+1 781-935-1200

sales@agiltron.com

www.agiltron.com

Information contained herein is deemed to be reliable and accurate as of the issue date. We reserve the right to change the design or specifications at any time without notice.
Agiltron is a registered trademark of Optowares Corporation in the U.S. and other countries.

Mini Erbium Doped Fiber Amplifier





DATASHEET

Modes Description

The EDFAs have both ACC mode - automatic current control or constant current control and APC mode - automatic power control settable via GUI. In the ACC mode, the pump laser's current is set by the user and automatically locked by the EDFA to achieve a constant pumping current. The EDFA's output power is proportional to the input power and has output even though the input signal is weak. In the APC mode, the user sets the output power, and the EDFA automatically maintains the output constant in a feedback laser pump control way. When the input optical power fluctuates, the APC mode minimizes the fluctuation of the output power and is suitable for power type and line type EDFA.

Typical Spectrums



P +1 781-935-1200

E sales@agiltron.com

W www.agiltron.com

Information contained herein is deemed to be reliable and accurate as of the issue date. We reserve the right to change the design or specifications at any time without notice. Agiltron is a registered trademark of Optowares Corporation in the U.S. and other countries.



Mini Erbium Doped Fiber Amplifier




DATASHEET

Typical Nanosecond Laser Pulse Amplification

- Source laser: 2.5kHz 200ns pulses with peak power 1.33mW
- Amplified 42dB by 23.5dBm EDFA;
- ASE floor is about 24dB lower than the peak power;



Gain Flattering Filter Effect



+1 781-935-1200

sales@agiltron.com

www.agiltron.com

Information contained herein is deemed to be reliable and accurate as of the issue date. We reserve the right to change the design or specifications at any time without notice. Agiltron is a registered trademark of Optowares Corporation in the U.S. and other countries.